




How to perform an autoscans on a Sony TV



NOTE: The steps to perform this procedure may be different depending on your TV model. ALWAYS refer to the User's Guide for your specific TV for complete information.

OPTION 1

1. Press the *Home* button on your remote control to display *TV Home Menu/XMB* and select the *Initial Setup* icon under the *Settings* category



2. Select the language for the on-screen display
3. Make sure the coax cable is plugged into your TV and select *Auto Program* to advance to the Auto Programming. This may take some time to complete. Cancelling this process will result in missing channels



4. Follow the on-screen instructions to complete the setup and begin viewing your TV



Need Help? Get in touch with Student Computing Services!

516-463-7777 option 1 | SCS@Hofstra.edu | www.Facebook.com/HofstraSCS

OPTION 2

1. Press the *Menu* or *Setup* button on your remote
2. When the menu opens, choose the *Settings* option
3. Navigate to the *Set-Up* or *Settings* menu (usually has an icon of a toolbox) and select it
4. Choose the *Digital Set-Up* option (*on some TVs, you may not need to select this option*)
5. In the *Digital Set-Up* screen, select the *Digital Tuning* option. You may need to press the *UP* button on your remote to get to it. The icon is for it may look like a wrench
6. Select *Digital Auto Tuning* and begin the tuning process. If prompted, choose *Cable* as your *TV Connection Type*. This may take some time to complete. Cancelling this process will result in missing channels